


VACUUM PACKAGING MACHINE

MODEL 250



OWNERS MANUAL (MANUEL D'UTILISATION) (MANUAL DE UTILIZACIÓN)

Service

- Use proper containers when draining the oil. Do not use food or beverage containers that may mislead someone into drinking from them. Properly dispose of the containers, or store in a safe place immediately following the draining of the oil.
- Prior to disposal, determine the proper method to dispose of waste from your local office of Environmental Protection Agency. Recycling centers are established to properly dispose of materials in an environmentally safe fashion.

Do not pour oil or other fluids into the ground, down a drain or into a body of water.



Warning-Your responsibility:

This machine should only be operated by personal who can read, understand and respect warnings and instructions regarding this machine in the owners manual.

INSTALLATION NOTICE FOR MODELS:

250, 300, 350, 350D, 380 & 450T

IN ORDER TO RESPECT NSF REGULATIONS:

The table on which the machine has to be installed, should be of open frame type, to avoid dirt accumulation, and to allow easy cleaning under the machine.

VACUUM PACKAGING MACHINE

MODEL 250

(MC-40)

GENERAL TABLE OF CONTENTS

I	OPERATION INSTRUCTIONS
II	MECHANICAL
	A- 250: front view assembly drawing.
	B- 250: rear view assembly drawing
	C- 250: front panel assembly
	D- Seal bar assembly drawings (twin seal)
	E- Seal bar assembly drawings (electrical bag cut option)
	F- 250: cover assembly drawing
	G- 250: upper seal bar assembly drawing
III	ELECTRICAL
	A- Electrical drawings
IV	PNEUMATIC
	A- Pneumatic drawing

VACUUM PACKAGING MACHINES

OPERATION INSTRUCTIONS

TABLE OF CONTENTS

1. Setting up the machine
2. Electrical connection
3. Operation
 - 3.1 Working principles
 - 3.2 Special packaging
 - 3.2.1 Gas flushing
 - 3.2.2 Electrical bag cut
 - 3.3 Setting of digital controls
 - 3.4 Daily cleaning
4. Trouble shooting
 - 4.1 Failure during a packaging cycle
 - 4.2 Insufficient vacuum
 - 4.2.1 Leakage in the bag
 - 4.2.2 No leakage in the bag
 - 4.2.3 Insufficient vacuum in the chamber
 - 4.3 Faulty seal
 - 4.3.1 Insufficient seal
 - 4.3.2 No seal
 - 4.3.3 Permanent sealing current
 - 4.3.4 Seal does not stick
 - 4.4 Fault in the valves
 - 4.5 Control board failure
5. Regular maintenance

VACUUM PACKAGING MACHINES

1. SETTING UP THE MACHINE:

Before choosing the site for the machine, please consider that you will also need room for packaged and non-packaged products apart from the space needed for the machine itself.

Keep in mind that the machine must not be set up upon uneven ground. Especially with mobile models, the weight of the pump might then cause warping of the machine. Then the lid will not fit correctly.

Before starting to work, check the oil view glass on the pump, if there is a sufficient quantity of oil in the pump. Never use oil other than recommended by the producer. Never exceed maximum quantity of oil indicated, when adding or changing oil. Verify weekly.

Due to the oil viscosity, the machine is hard to start when temperatures are very low. Therefore the pump should be put in a room with an air temperature of at least 50°F (+10°C). On the other hand, there must be free access of air to the pump to allow for cooling so that operation temperature of 160°F (70°C) is not exceeded.

2. ELECTRICAL CONNECTION:

Electrical connections must be made by qualified personnel. This person must make sure that the electrical entries corresponds to the proper voltage and amperage of the machine.

All vacuum machines are supplied with an electrical schematic drawing.

An important step in connecting the machine is to make sure that the pump turns in its correct rotation.



The pump should not rotate more than 3 to 4 seconds in the wrong rotation or it may cause serious damage. The proper rotation is indicated by an arrow on the pump motor.


3. OPERATION:

3.1 Working principles:

A vacuum packaging cycle is made of 3 stages. First the vacuum is made, the air is completely taken out of the chamber and from bag containing the product. (See figure 1). Then it is possible to inject neutral gas from the nozzles, if the product is delicate. Finally, a mechanism pushes the sealing bar to the rubber support to seal the bag.

To obtain nice packages, the products and the bags have to be of proportional sizes. The bag's opening should never exceed 50 cm(2") past the seal bars. The product should be centered in height in relation to the seal bar by adjusting the spacers provided.

To obtain a good seal, make sure that no residue of fat is left between the bag's inner sides where sealing is done.



3.2 Special packaging:

3.2.1 Gas flushing (option):

There is an atmospheric pressure of 1 kg/ sq. cm (14 lbs/sq. inch) upon products when fully evacuated. Products which can be damaged by high pressure must be packaged with a partial vacuum, or the pressure must be counterbalance by inflating the bag with gas (nitrogen or carbon dioxide) before sealing after evacuation.

For gas flushing, the bags are placed on the sealing bars, the open end placed over the gas nozzles mounted alongside the sealing bar. After evacuation, the vacuum valve closes and the gas valve opens. Gas time (sec.) can be set in the program menu.

The necessary gas tank and pressure valve mounted on tank is not supplied, The pressure of the gas regulator should be set at approximately 1/3 kg/sq. cm (5 lbs/sq.inch.). Each machine has an adaptor for gas connection when gas flush option is ordered.

3.2.2 Electrical bag cut (optional):

This option is used to obtain a package that the excess bagtail is cut off close to the seal (cannot be used with top and bottom sealing).

3.3 Vacuum packaging operation:

Note: Refer to the menus structure on page 10 and the keyboard detail on page 11.

3.3.1 Basics:

Use key "POWER" to power ON / OFF the vacuum packaging machine. When the unit is energized, the identification of the last executed program is displayed on LCD screen.

Use the "ESC" key to change over from the programs menu to the functions menu and from the functions menu to the programs menu.

In functions menu, use key "SELECT" to select a function and key "ENTER" to accedeand executed the selection.

In programs menu, use key "SELECT" to select a program and key "ENTER" to accede and modify the selection.

In programs submenu, use key "ENTER" to pass over the parameters and point to the following one; the parameters are blinking to point out the acquisition mode. A return to programs menu is performed automatically following the last parameter acquisition.

In program submenu, use key "ESC" to get back to the programs menu. Strike any key to clear the error messages which may be displayed on LCD screen.

3.3.2 Functions menu:

3.3.2.1 Create a program:

When executing the "create a program" function, the program submenu is acceded, starting with the identification. The initial identification "Pxx NO NAME" is given to the program and all parameters are established to zero; the program number is allocated automatically.

3.3.2.2 Delete a program:

When executing the "delete a program" function, the programs menu is accessed and the number of the first program in memory is blinking to point out the deletion mode. Use key "SELECT" to select a program and key "ENTER" to accede and confirm deletion of the selection. Use key "ESC" to unconfirm a deletion and to leave the function. When leaving the function, the number of the actual program on LCD screen cease to blink.

3.3.2.3 Select operating mode:

When executing the "select operating mode" function, which is available only for the automatic units, the actual selection is blinking to point out the acquisition mode. Use key "SELECT" to get through the operating modes, which are automatic, semi-automatic and manual; the validation of the selected operating mode is performed automatically. Use key "ESC" or "ENTER" to leave the function and get back to the program menu.

3.3.3 Programs menu:

3.3.3.1 Program identification:

For a selected program, set the identification, using the numeric keyboard characters chart; press numeric key until the desired character is selected (4 times for the numeric value). Use key "ENTER" to validate the character and to validate the characters string at the end(the new characters string is blinking). In a middle of an acquisition, use key "ESC" to come backward and erase one of several characters.

Example: EXAMPLE 1 → keys 2, 2, ENTER → E
(9 characters) → keys 8, 8, 8, ENTER → X
→ keys 1, ENTER → A
→ keys 5, ENTER → M
→ keys 6, ENTER → P
→ keys 4, 4, 4, ENTER → L
→ keys 2, 2, ENTER → E
→ keys 9, 9, 9, ENTER → space
→ keys 1, 1, 1, 1, ENTER → 1
key ENTER to validate the characters string

3.3.3.2 Vacuum time setting:

For a selected program set the vacuum time, in seconds; the validation is automatically performed following the second digit entry (the new vacuum time is blinking). In a middle of an acquisition, use key "ENTER" to validate the vacuum time and key "ESC" to come backward and start over with a new acquisition (the old vacuum time is blinking).

Examples: 1s → keys 0, 1 or 1, ENTER
15s → keys 1, 5

3.3.3.3 Gas time setting:

For a selected program set the gas time setting following the same procedure as for the vacuum time. Keep in mind that increasing gas time decrease sealing pressure. Some vacuum must be kept inside to assure proper functioning.

3.3.3.4 Sealing time setting:

For a selected program set the sealing, starting with the seconds; the decimal point is automatically inserted following the first digit entry and the validation is automatically performed following the third digit entry (the new sealing time is blinking). The sealing time is truncated to the nearest half hundredth. In a middle of an acquisition, use key "ENTER" to validate the sealing time and key "ESC" to come backward and start over with a new acquisition (the old sealing time is blinking).

Examples: 4.50s → keys 4, 5, 0 or 4, 5, ENTER or
keys 4, 5, 1 or 4, 5, 2 or 4, 5, 3 or 4, 5, 4
2.35s → keys 2, 3, 5 or
keys 2, 3, 6 or 2, 3, 7 or 2, 3, 8 or 2, 3, 9
0.00s → keys 0, 0, 0 or 0, ENTER

3.3.4 Vacuum cycle execution:

For the manual units and the automatic units set on manual, close the cover to initiate a vacuum cycle. For the automatic units set on semi-automatic or on automatic, use push button "STOP / START" to initiate or interrupt a vacuum cycle. A selected program can be initiated only in the programs menu, when no modifications are in progress, and the access to the other programs and functions is denied. During cycle execution the operation status is sequentially displayed on LCD screen, except for the parameters established to zero, which are not displayed:

- vacuum time status during vacuum sequence,
- gas time status during gas flush sequence,
- sealing time status during sealing sequence,
- ATM message level during atmosphere sequence.

During cycle execution, use key "1" to abort the vacuum sequence and execute the following sequence, which is gas flush or sealing, and key "ENTER" to accede and modify the program; the parameters become valid only for the following vacuum cycles.

3.3.5 System monitor:


To accede the diagnostics menu, power up the vacuum packaging machine while keeping pushed in the "ESC"key. Use key "SELECT" to select the system monitor function and key "ENTER" to accede and visualize the monitored parameters. Use key "SELECT" to change over from the software revision, the amount of working hours done and the amount of complete cycles performed since first initialization.

-MENUS STRUCTURE-

- **Functions menu:**
 - "F1 CREATE A PRGM"
 - "F2 DELETE A PRGM"
 - "F3 SELECT OPMODE" (automatic units only)
- **Programs menu:**
 - "Pxx NAME"
 - Program submenu:
 - "VACUUM: xx.xs" (10 – 199s)
 - "GAS FLUSH: xx.xs" (0 – 99s) (units with gas option)
 - "SEAL TIME: x.xxs" (0.00s - maximum unit allocated setting)
 - "Pxx NAME" (12 characters)
- **Diagnostics menu (keys "ESC" & "POWER" for access):**
 - "DIAGNOSTICS MENU" (access code required)
 - "D1 INPUTS TEST"
 - "D2 OUTPUTS TEST"
 - "D3 MODEL SELECT"
 - "D4 GAS OPTION"
 - "D5 SEALING TIME"
 - "D6 COOLING TIME"
 - "D7 OFFSET CALIB."
 - "D8 VACUUM SENSOR"
 - "D9 SIPROMAC PUB"
 - "D10 LOADING TIME" (automatic units only)
 - "D11 UNLOADNG TIME" (automatic units only)
 - "SYSTEM MONITOR" (no access code required)
 - "SOFTWARE: R x.xx"
 - "WORK HRS: xxxxx"
 - "CYCLES: xxxxxxx"

-KEYBOARD DETAILS-

MC-40 CONTROLS





WARNING: All electrical work described in this brochure should be done by a QUALIFIED and AUTHORIZED technician.

3.4 Daily cleaning:

For hygienic cleanliness, it is imperative to clean chamber and spacers daily. Also clean the lid rubber to assure tight seat of the lid.

4. TROUBLE SHOOTING:

4.1 Failure during packaging cycle:

4.1.1 "COVER DOWN ERROR" message is displayed on LCD(manual units):

The input signal of the down position switch has been lost during cycle execution.
- Check limit switch adjustment.

4.2 Insufficient vacuum:

4.2.1 Leakage in the bag:

Most frequently, insufficient vacuum in bags is due to leakage in bag and not due to any fault of the machine.

Pin-hole leak for which there is no obvious explanation is due to faulty bag material.

Pin-hole leak caused by sharp edge of the product (bone, etc.). Use bone-guard or thicker film.

Tear in bag by careless handling (sharp edge on filling table, damage made by retailer or customer).

Leakage in lateral or bottom seal, complain to supplier of bags or film.

4.2.2 No leakage in the bag:

Bag is too large, therefore the surplus of air remains visible (there is surplus of air in 0.4% of the bag volume in each bag). Use bags of suitable size.

Vacuum time is too short:

Pressure bar is jammed and closes opening of bag during evacuation.

4.2.3 Insufficient vacuum in chamber:

If troubles described under 4.2.1 and 4.2.2 do not apply, there is something wrong with the evacuation. To find the leakage quickly, check for leaks with a precision vacuummeter, going back step by step from the chamber to the pump.

At the chamber (measuring point at base of valve) at maximum time of evacuation. If more than 6 torr, proceed directly to the pump, if more than 3 torr: have pump service by pump supplier. If pressure at pump is good, reconnect hoses to pump and measure again.

Verify at vacuum hose connections and valve connections.

When proceeding this way, starting from pump, loss of pressure per step must not exceed 0.5 to 1 torr.

Warning: Verify connections of measuring equipment before verifying machine.

Most frequent points of leakage: lid gasket, damaged vacuum hose or loose hose clamps.

4.3 Faulty seal:

4.3.1 Insufficient seal:

Damaged teflon or silicone rubber.

Sealing pressure too low, bellows leaking or pressure bar jammed.

Leakers in seal: heating wire mechanically damaged (knicked) or silicone rubber uneven.

4.3.2 No seal:

Sealing wire burnt.

Faulty contact in sealing circuit.

Sealing transformer burnt through.

Contactors do not work.

4.3.3 Permanent sealing current:

Contactors are jammed check sealing transformer for damage through overload.

4.3.4 Seal does not stick:

Insufficient layer of polyethylene (inferior quality of bags).

Seal area extremely contaminated by fat or meat juice. Use filling aid.

Sealing temperature is too low (when using very thick films).

Warning: Do not increase sealing time more than really necessary; higher temperature will reduce working life of teflon and silicone rubber.

4.4 Fault in the valve:

Vacuum or air valve does not open.

Check whether there is voltage on the magnetic valves during their period of operation. If there is no voltage a wire is broken or the PC board is damaged.

Lid does not open at the end of the cycle; air enters, but there is still 20 - 40% vacuum in chamber. Vacuum valve does not close.

4.5 MC40 Control board failure

NOTE: Refer to menu structure on page 9.

This board software is allowing access to a "Diagnostics Menu". Only qualified service technicians are authorized to access this menu by entering a security password.

By acceding either the "D1 input test" feature or the "D2 output test" feature, a trained technician will be able to quickly know the origin of the problem: pump, sealing system, pneumatic problem, security switches problem, etc...

Keep in mind that in most cases trouble is due to a leakage, loose electrical Keynesian or evident damage to the main component: vacuum pump, valves..., electrical contactors, thermal overload, fuses holder or transformer.

For assistance do not hesitate to contact your local service technicians.

5. Regular maintenance:

Routine controls to be made at regular intervals:

Check teflon for wear.

Check silicone rubber for burnt spots and smooth even position.

Check pressure bar for jamming.

Check lid sealing for damage and hardened spots.

Check switch-point of micro switch, adjust if necessary.


Check evacuation hose for damage (contraction of diameter, or abrasions).

Check vacuum connections for tightness.


Check oil in pump (oil level in view glass; add if necessary. Regular change of oil - necessity indicated by change of color).

Check vacuum in chamber with precision vacuumeter.

Check function of cycle with various settings of timers.




MECHANICAL DRAWING



005A0523

ITEM	#PART	DESCRIPTION	QT.
1	004-0406	VACUUM 250 PRE-ASSY	1
2	002A2282	SEAL BAR GUIDE BLOCK	2
3	005A0497	SEAL BAR ASSEMBLY	1
4	005A0520	BAG CUT SEAL BAR ASSEMBLY	1
5	005A1000	BELLOWS ASSEMBLY	1
6	005-0522	COVER ASSEMBLY	1
7	005A0526	FRONT PANEL ASSEMBLY	1
8	005A0519	FILLER PLATE ASSEMBLY	1
9	051-0740	FLAT WASHER 1/4" S/S	4
10	051-0581	NUT 1/4"-20 NC. LOCK NYLON S/S	4
11	051-0780	FLAT WASHER 3/8" S/S	1
12	051-0620	HEX. NUT 3/8"-16 NC. S/S	1
13	051-0264	SCREW 1/4"-20 NC. X 2" PAN PHIL. S/S	4
14	056-0020	SPRING NUT 1/4"-20 NC.	4
15	058-0030	SPACERS	2
16	004A1651	COVER HOLD DOWN PRE-ASSY	1



NOTE: - USE THIS DRAWING ALONG WITH DRAWING #005A0527 TO ASSEMBLE THE MACHINE. NO PARTICULAR ORDER SHOWN.



NOTE: - INSTALL ITEM (19) SO THAT IT CAN MOVE FREELY BUT WITHOUT TOO MUCH LOOSENESS

MACHINE	250	TEL. MARKING	INCH METRIC	ST-GERMAIN DE GRANTHAM QUEBEC CANADA
PART	MACHINE ASSEMBLY FRONT VIEW	UNITS	1/16 1/32 1/64	
ITEM		DATE	06-08-06	
DATE	06-08-06	BY	M.A.L.	
APP.		INT.		
NO.		DT.	M-1	1
				5A0523

LET.	
G. REDRAWN	
DATE	06-08-04
INT.	M.A.L.

005A0526


ITEM	PART #	DESCRIPTION	QT.
1	001A1824	FRONT PANEL	1
2	051-0089	SCREW 4-40 x 1" FLAT SLOT SS	4
3	051-0713	WASHER #4 FLAT S/S	4
4	058-0120	CPVC SPACER 0.120" x 1/4" x 5/8"	4
5	051-0540	NUT #4-40 HEX S/S	8
6	051-0715	WASHER #4 LOCK SS	4
7		GROUND WIRE	1
8	051-0144	SCREW #10-24 N.C 1/2" PAN PHIL. S/S	1
9	051-0571	NUT #10-24 S/S	1
10	001-1869	VACUUM GAGE FIXATION RING	1
11	114-0260	VACUUM GAGE W/ SUPPORT	1
12	101-0160	ELBOW 90° 1/4" FNPT x 1/4" HOSE	1



DETAIL A

033-0015 OR 033-0017
OR 033-0018 KEYBOARD REF.
(NOT INCLUDED)

POSITION CAREFULLY IN REGARDS
TO OPENING IN ITEM #1




A

MACHINE		250		DEPT. TOL. METRIC INCH		SIPROMAC	
PART		FRONT PANEL ASSEMBLY		TOLERANCE		ST. GERMAIN DE GRANTHAM	
ITEM		CNC		DRAUGHT		QUEBEC CANADA	
PART.		DWG. BY J.G.		DATE 04-10-13		M	
		APP. BY		55-11-03		QTY. 1	
						005A0526	

E	001A	WAS 004A0362 MODIF #A-0415	04-11-11	M.A.
D	REDE	RE S.E. MODIF. #A-0408 (MC-40)	04-10-13	J.G.
LET.		MODIFICATION	DATE	INT.

ITEM	PART #	DESCRIPTION	QTY.
1	004-0334	SEAL BAR PRE-ASSEMBLY	1
2	001-1738	SEAL BAR GUIDE	2
3	001-1829	SEAL BAR GUIDE SPACER	2
4	001A2757	SEAL BAR SUPPORT	1
5	051-0230	HEX. BOLT 1/4"-20 NC. X 1 1/4" S/S	4
6	051-0740	FLAT WASHER 1/4" S/S	4
7	051-0581	NUT 1/4"-20 NYLON LOCK S/S	4
8	051-0195	FLAT HEAD SCREW 1/4"-20 NC. X 3/4" S/S	3
9	038-0230	WRING DUCT W/ ADH. BACK. (0.36" X 0.5" X 170) 0.385	1




MACHINE	250	SCALE	QT.
PART	SEAL BAR ASSEMBLY	DATE	05-09-27
ITEM:	BY: M. ALLEBLANC	DATE	05-10-27
MAP:	APP.	NO.	005A0497
SIPROMAC		ST-GERMAIN DE GRANTHAM QUEBEC CANADA	

C	REDRAWN/ MODIFIED ITEM #4	M.A.L.
LET.	MODIFICATION	INT.
	DATE	

1004-0334

ITEM	#PART	DESCRIPTION	QT.
1	002A0433	SEAL BAR	1
2	002-0031	CONNECTOR	2
3	039-0200	SEALING ELEM. STD TWIN (2x460mm EA.)	3.02
4	052-0395	SET SCREW 1/4" - 20 NC. X 5/16" (OVAL POINT)	4
5	052-0250	SET SCREW #8-32 NC. X 1 1/2" ROUND SLOT BRASS S/S	2
6	051-0550	HEX. NUT #8-32 NC. S/S	4
7	176-0202	TEFLON TAPE .005" x 1-1/2" ADHES. (330mm EA.)	0.042
8	027-0400	CONNECTOR ADAPTOR	2




NOTE:
CUT OFF HEAD
OF SCREW AFTER
ASSEMBLING

MACHINE	250	INCHES	1/8"	1/16"	1/32"	1/64"	1/128"	1/256"	1/512"	1/1024"
PART	SEAL BAR PRE-ASSEMBLY	TOLERANCE	± 0.5	± 0.3	± 0.2	± 0.1	± 0.05	± 0.025	± 0.0125	± 0.00625
ITEM		SCALE	N.T.S.							
DATE	98-04-06	BY	PROVENCHE	DATE	98-04-06					
APP.		DATE	98-04-06							
SIPROMAC		ST-GERMAIN DE GRANTHAM		QUEBEC CANADA						
1		1		1						
1004-0334										

B	MODIFICATION	A-0000	(CONNECTEUR)	04-04-19	J.G.
A	REDRAWN/REMOVED		HOLES ON THE SEAL BAR	98-04-06	A.P.
LET.				DATE	INT.

ITEM	PART #	DESCRIPTION	QT.
1	004-0335	SEAL BAR PRE-ASSEMBLY	1
2	001-1738	SEAL BAR GUIDE	2
3	001-1829	SEAL BAR GUIDE SPACER	2
4	001A2757	SEAL BAR SUPPORT	1
5	051-0230	HEX. BOLT 1/4"-20 NC. X 1 1/4" S/S	4
6	051-0740	FLAT WASHER 1/4" S/S	4
7	051-0581	NUT 1/4"-20 NYLON LOCK S/S	4
8	051-0195	FLAT HEAD SCREW 1/4"-20 NC. X 3/4" S/S	3
9	038-0230	WRING DUCT W/ ADHL. BACK. (0.36" X 0.5" X 170) 0.585E	1




-BAG CUT OPTION-

MACHINE	250	NO. OF TOLERANCE	STIPROMAC
PART	SEAL BAR ASSEMBLY	NO. OF TOLERANCE	ST-GERMAIN DE GRANBHAM
ITEM		NO. OF TOLERANCE	QUEBEC CANADA
MAT		SCALE	1
		DATE	05-09-27
		APP.	005A0520

LET.	C	REDRAWN/ MODIFIED ITEM #4	05-09-27	M.A.L.
		MODIFICATION	DATE	INT.

005B0522

ITEM	PART #	DESCRIPTION	QT.
1	002A0438	PLEXI COVER	1
2	004A0309	COVER HINGE ASS'Y	1
3	051-0233	SCREW 1/4-20 X 1-1/4" PAN PHIL S/S	4
4	051-0740	WASHER 1/4" FLAT S/S	10
5	051-0750	WASHER 1/4" LOCK S/S	4
6	051-0580	NUT 1/4"-20nc. S/S	4
7	004A0308	UPPER SEAL BAR PRE-ASS'Y	1
8	051-0249	SCREW 1/4-20x 1-1/2" PAN PHIL SS	2
9	179-0005	NEOPRENE SPONGE 3/8" O.D. 5.47	1
10	076-0010	"O" RING 1/4" x 3/8" x 1/16"	2
11	002-0437	UPPER SEAL BAR SPACER	2




MACHINE		250		DEPT. FOR METRIC INCH		SIPROMAC	
PART		COVER ASSEMBLY		UNITS ± 0.015 ± 0.03 ± 0.027		ST-GERMAIN DE GRANTHAM QUEBEC CANADA	
ITEM		CRC		SOUDAGE ± 0.5		N.T.S.	
DATE		05-05-09		DATE		05-05-09	
BY		M.A.L.		DATE		05-05-09	
APP. BY		[Signature]		DATE		05-05-09	
MATERIAL		M-1		DEPT.		M-1	
QTY.		1		NO.		005B0522	

E	051-0233 WAS 051-0249, 051-0249 WAS 051-0257, MODIF #A-0134	05-04-19	M.A.
D	REDRAWN	05-05-09	M.A.
LET	MODIFICATION	DATE	INT.

1004A0308

ITEM	PART #	DESCRIPTION	QTY
1	002A0436	UPPER SEAL BAR SUPPORT	1
2	008-0435	UPPER SEAL BAR RUBBER	1



380	2
250	1

SIPROMAC
ST-GERMAIN DE GRANTHAM
QUEBEC CANADA

SCALE: _____


NO. **004A0308**

DATE: 99-08-02



BY: S. LAROUICHE


APP. *LT*

B	AJOUTER 380	03-02-13	Y.C.
A	REDRAVN	99-08-02	S.L.
LET.	MODIFICATION	DATE	INT.




ELECTRICAL DRAWING






category system	VACUUM PACK	model MC-40	vol. circuit	1Ph 60Hz				SIPROMAC
				year	month	day	block	
usual fonctions				05	02	03		SK-Germain de Grantham QUEBEC, CANADA
options				PP	PP	DL	DL	
								1 de 3



TRANSF. CONT.



category	VACUUM PACK	model	250 MC-40	volt.	24V 60Hz
system	Control	circuit	control	year	05
usual	MC-40	concept	PP	month	02
fonctions		draw	PP	day	03
options		app	DL	block	
SIPROMAC St-Germain de Grantham QUEBEC, CANADA					
006-0020 PAGE 2 de 3					




PNEUMATIC DRAWING



007-0035

ITEM	PART #	DESCRIPTION	QT.
1	114-0260	VACUUM GAUGE	1
2	106-0070	BELLOWS VALVE	1
3	106-0020	ATMOSPHERE VALVE	1
4	106-0020	VACUUM VALVE	1



MACHINE		250		SIPROMAC	
PART		PNEUMATIC DRAWING		ST-GERMAIN DE GRANTHAM QUEBEC CANADA	
ITEM:	ONG:	DATE	DATE	SCALE	QT.
MAT:	BY	96-11-06			1
	APP.				
MODIFICATION			DATE	INT.	
LET.					007-0035


NOTES




250




300




350/350D




380A




450T




400A




450A




550A



580A




420A




600A


VACUUM PACKAGING MACHINES




620A




650A



680A



700A



750A