

# BKI Fry Warmer

MODELS HFW, HFWB, HFWS  
Service Manual



*Fresh ideas in foodservice equipment*

## BKI LIMITED WARRANTY

2812 Grandview Dr. • Simpsonville, SC 29680 • USA  
(864) 963-3471 • Toll Free: (800) 927-6887 • Fax: (864) 963-5316

### WHAT IS COVERED

This warranty covers defects in material and workmanship under normal use, and applies only to the original purchaser providing that:

- ☐ The equipment has not been accidentally or intentionally damaged, altered or misused;
- ☐ The equipment is properly installed, adjusted, operated and maintained in accordance with national and local codes, and in accordance with the installation and operating instructions provided with this product.
- ☐ The serial number rating plate affixed to the equipment has not been defaced or removed.

### WHO IS COVERED

This warranty is extended to the original purchaser and applies only to equipment purchased for use in the U.S.A.

### COVERAGE PERIOD

- ☐ Warranty claims must be received in writing by BKI within one (1) year from date of installation or within one (1) year and three (3) months from data of shipment from the factory, whichever comes first.
- ☐ COB Models: One (1) Year limited parts and labor.
- ☐ COM Models: Two (2) Year limited parts and labor. COM convection ovens also have a two (2) year door warranty.
- ☐ CO1 Models: Two (2) Year limited parts and labor. Five (5) Year limited door warranty.
- ☐ BevLes Products: Two (2) Year limited parts and labor.
- ☐ Warranty period begins the date of dealer invoice to customer or ninety (90) days after shipment date from BKI, whichever comes first.

### WARRANTY COVERAGE

This warranty covers on-site labor, parts and reasonable travel time and travel expenses of the authorized service representative up to (100) miles round trip and (2) hours travel time and performed during regular, weekday business hours.

### EXCEPTIONS

Any exceptions must be pre-approved in advance and in writing by BKI. The extended door warranty on convection ovens years 3 through 5 is a parts only warranty and does not include labor, travel, mileage or any other charges.

### EXCLUSIONS

- ☐ Negligence or acts of God,
- ☐ Thermostat calibrations after (30) days from equipment installation date,
- ☐ Air and gas adjustments,
- ☐ Light bulbs,
- ☐ Glass doors and door adjustments,
- ☐ Fuses,
- ☐ Adjustments to burner flames and cleaning of pilot burners,
- ☐ Tightening of screws or fasteners,
- ☐ Failures caused by erratic voltages or gas suppliers,
- ☐ Unauthorized repair by anyone other than a BKI Factory Authorized Service Center,
- ☐ Damage in shipment,
- ☐ Alteration, misuse or improper installation,
- ☐ Thermostats and safety valves with broken capillary tubes,
- ☐ Freight - other than normal UPS charges,
- ☐ Ordinary wear and tear,
- ☐ Failure to follow installation and/or operating instructions,
- ☐ Events beyond control of the company.

### INSTALLATION

Leveling, as well as proper installation and check out of all new equipment - per appropriate installation and use materials - is the responsibility of the dealer or installer, not the manufacturer.

### REPLACEMENT PARTS

BKI genuine Factory OEM parts receive a (90) day materials warranty effective from the date of installation by a BKI Factory Authorized Service Center.

---

# Table of Contents

<b>Table of Contents</b> .....	<b>1</b>
<b>Introduction</b> .....	<b>2</b>
Safety Precautions.....	2
Safety Signs and Messages.....	2
Safe Work Practices.....	2
Safety Labels .....	4
<b>Installation</b> .....	<b>5</b>
Instructions For Shipping Damage .....	5
Electrical Information And Grounding.....	5
Installation Instructions .....	5
<b>Operation</b> .....	<b>6</b>
Unit Startup and Preheating .....	6
Operational Guidelines .....	6
Unit Shutdown .....	6
<b>Maintenance</b> .....	<b>7</b>
Scheduled Maintenance .....	7
Cleaning .....	7
Troubleshooting .....	11
Repair .....	12
Lamp Replacement .....	12
<b>Replacement Parts</b> .....	<b>13</b>
Components .....	13
HFW .....	13
HFWB.....	14
HFWS.....	15
Accessories .....	16
<b>Wiring Diagrams</b> .....	<b>17</b>
HFW.....	17

---

## Introduction

Congratulations! You have chosen a **Fry Warmer** that will give you many years of fine service from the original manufacturer, **BKI**.

The **BKI** name and trademark on this unit assures you of the finest in design and engineering — that it has been built with care and dedication — using the best materials available. Attention to the operating instructions regarding proper installation, operation, and maintenance will result in long lasting dependability to insure the highest profitable return on your investment.

### NOTICE

PLEASE READ THIS ENTIRE MANUAL BEFORE OPERATING THE UNIT. If you have any questions, please contact your **BKI** Distributor. If they are unable to answer your questions, contact the **BKI** Technical Service Department, toll free: 1-800-927-6887. Outside the U.S., call 1-864-963-3471.

This unit must be sealed to the counter after it is installed to conform to NSF Standard 4, Item 4.28. (Dow Corning RTV #732 Multi purpose Sealant.)

## Safety Precautions

Always follow recommended safety precautions listed in this manual. Below is the safety alert symbol. When you see this symbol on your equipment, be alert to the potential for personal injury or property damage.



## Safety Signs and Messages

The following Safety signs and messages are placed in this manual to provide instructions and identify specific areas where potential hazards exist and special precautions should be taken. Know and understand the meaning of these instructions, signs, and messages. Damage to the equipment, death or serious injury to you or other persons may result if these messages are not followed.

### DANGER

This message indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury.

### WARNING

This message indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury.


### CAUTION

This message indicates a potentially hazardous situation, which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

### NOTICE


This message is used when special information, instructions or identification are required relating to procedures, equipment, tools, capacities and other special data.

## Safe Work Practices



### Beware of High Voltage

This equipment uses high voltage. Serious injury can occur if you or any untrained or unauthorized person installs, services, or repairs this equipment. Always Use an Authorized Service agent to Service Your Equipment.



### Keep this manual with the Equipment

This manual is an important part of your equipment. Always keep it near for easy access. If you need to replace this manual, contact:

#### **BKI**


Technical Services Department  
2812 Grandview Drive  
Simpsonville, S.C. 29680  
Or call toll free: 1-800-927-6887  
Outside the U.S., call 864-963-3471



### Protect Children

Keep children away from this equipment. Children may not understand that this equipment is dangerous for them and others.

NEVER allow children to play near or operate your equipment.




### Keep Safety Labels Clean and in Good Condition

Do not remove or cover any safety labels on your equipment. Keep all safety labels clean and in good condition. Replace any damaged or missing safety labels. Refer to the Safety Labels section for illustration and location of safety labels on this unit. If you need a new safety label, obtain the number of the specific label illustrated on page 4, then contact:

#### **BKI**

Technical Services Department  
2812 Grandview Drive  
Simpsonville, S.C. 29680  
Or call toll free: 1-800-927-6887  
Outside the U.S., call 864-963-3471




### Be Prepared for Emergencies

Be prepared for fires, injuries, or other emergencies.

Keep a first aid kit and a fire extinguisher near the equipment. You must use a 40-pound Type BC fire extinguisher and keep it within 25 feet of your equipment.

Keep emergency numbers for doctors, ambulance services, hospitals, and the fire department near your telephone.



### Know your responsibilities as an Employer

- Make certain your employees know how to operate the equipment.
- Make certain your employees are aware of the safety precautions on the equipment and in this manual.
- Make certain that you have thoroughly trained your employees about operating the equipment safely.
- Make certain the equipment is in proper working condition. If you make unauthorized modifications to the equipment, you will reduce the function and safety of the equipment.

### Safety Labels


N0200



N0202



N0444



N0158



## Installation

**⚠ WARNING**

Serious injury, equipment damage or death could result if attempting to install this unit yourself. Ensure that an authorized BKI service agent install the oven.

### ***Instructions For Shipping Damage***

You are responsible for filing all freight claims with the delivering truck line. Inspect all cartons and crates for damage when they arrive. If there is damage noted to shipping crates or cartons, or, if a shortage is found, note this on the bill of lading (all copies) before signing.

If damage is detected when the equipment is uncrated, immediately call the delivering truck line and follow up the call with a written report indicating concealed damage to your equipment. Ask for an immediate inspection of your concealed damage item. Crating material **MUST** be retained to show the inspector from the truck line.

### ***Electrical Information And Grounding***

**⚠ WARNING**

Electrocution, equipment failure or property damage could result if an unlicensed electrician performs the electrical installation. Ensure that a licensed electrician perform the electrical installation in accordance with local codes, or in the absence of local codes, with the National Electrical Code, ANSI NFPA 70-20XX.

HFW's are wired for use in accordance with all applicable local, state, and federal codes. For specific electrical requirements and connections refer to the wiring diagram attached to the unit or provided in the Service Manual.

### ***Installation Instructions***

**NOTICE**

If a side or back panel is removed on the chute, the other two sides must be sealed with NSF approved silicone. Seal all inside seams greater than 1/32".

1. Obtain a suitable countertop location for the unit that will provide a clearance of 4" from the rear louvers.
2. Plug unit into 20 amp, 120 volt receptacle.

## Operation

### ***Unit Startup and Preheating***

1. Turn on power to the unit.
2. Allow the equipment to preheat for ten (10) minutes before loading it with product.

### ***Operational Guidelines***

- Foods should be a minimum of 195° F. before being placed in the warmer.
- Foods loaded in first should be served first as much as is practical.
- Check Federal and State Health and Sanitation Regulations for internal temperature required for holding cooked foods for sale. Maintaining these temperatures often tends to continue to cook certain products. Therefore, smaller amounts of bulk foods should be displayed at non-peak periods and the warmer refilled as needed.

### **NOTICE**

This equipment is designed to hold foods for a short period of time only.

### ***Unit Shutdown***

1. Remove all food from the equipment.
2. Turn off power to the unit.
3. Allow the equipment to cool to room temperature.
4. Remove any residue and clean the equipment thoroughly.



---

## Maintenance

**⚠ CAUTION**

Failure to comply with the maintenance below could result in a serious accident.

**⚠ WARNING**

Electrocution, equipment failure or property damage could result if an unlicensed electrician performs electrical repair. Ensure that a licensed electrician perform electrical repair.

### *Scheduled Maintenance*

#### Cleaning

This unit should be cleaned at the end of each working day. Use the following procedure:

**⚠ DANGER**

Failure to remove power from this unit may cause severe electrical shock. This unit may have more than one disconnect switch.

**⚠ CAUTION**

Never use abrasive cleaners that may damage the finish.

Never steam clean the interior.

Avoid getting excess water in the interior of the unit.

Do not clean the heater/blower assembly by applying compressed air.

Do not leave this unit on and unattended after business hours.

1. Turn the unit off and allow it to cool down to room temperature.
2. Remove any food from unit.
3. Remove Flat Surface Insert by lifting vertically.



4. Remove Package Staging Rack by tilting forward(a) then lifting vertically(b).



a.



b.

5. Remove the Pan Divider by lifting it out of the pan vertically.



6. Remove the Pan by picking up on the front then lifting entire pan vertically.



7. Use a nylon brush(a) to thoroughly clean grease and debris from holes in pan. Be sure to clean top and bottom of pan, pan divider, staging rack, and flat surface insert with hot soapy water. Rinse well and dry(b).



a.



b.

8. Slide Crumb Drawer(a) out and remove(b) from machine. Use a nylon brush to clean Crumb Tray. Rinse and dry.



a.



b.

9. When cleaning, use a small nylon brush to remove debris from Blower Grid.



10. After brushing grid, use a clean cloth to wipe the debris and oil from grid and machine.



**⚠ WARNING**

Do not spray any cleaning chemicals or any other liquid into blower grid. This could cause a risk of shock or prevent the machine from working properly.

11. Clean surface underneath crumb tray with a hot rag to remove any shortening/debris that may have spilled onto bottom well. After unit and components have been cleaned, reinstall crumb tray, pan, pan divider, staging rack, and flat surface insert.



## Troubleshooting

Refer to the table below for troubleshooting information.

<b>Problem</b>	<b>Cause</b>	<b>Possible Solution</b>
<b>Package Holding Area is not holding heat</b>	Ceramic heating element failure	Contact an authorized BKI service agent for corrective action.
<b>Noisy fan</b>	Fan blade is dirty or fan bearings are failing	Contact an authorized BKI service agent for corrective action.
<b>Package Holding Area is not heating and perforated pan is not heating</b>	No power to unit.	Make sure that the circuit breaker and switch at the power supply are supplying power to the unit. If problem persists, contact licensed electrician.
<b>Pilot light on Hood Illuminated</b>  <b>Package Holding Area is heating and the perforated pan is not heating</b>	Fan has overheated and cut off  Or  Heating coil has failed	Wipe the dust from the air intake louvers to allow proper airflow and prevent fan overheating. Also check exhaust grid for blockage and clean if necessary. Turn the power switch off. Wait 60 seconds. Turn the power switch back on.  Contact an authorized BKI service agent for corrective action.

## **Repair**

### **NOTICE**

Before replacing any parts, make sure the power has been turned off and the unit has cooled down.

## **Lamp Replacement**

### **NOTICE**

Only use PTFE-coated lamp to prevent glass contamination.


1. Make sure power to the unit is OFF and the unit has cooled down.
2. Carefully remove the faulty lamp.
3. Replace with the new lamp.

## Replacement Parts

Use the information in this section to identify replacement parts. To order replacement parts, call your local BKI sales and service representative. Before calling, please note the serial number on the rating tag affixed to the unit.


### Components

#### HFV



PART #	QTY	DESCRIPTION
B0066	1	BULB, 40A15 130V PTFE COATED
C0119	1	CALROD, 120V 1000W 140C C/U SWITCH
C0080	2	CALROD, 120V 400W CERAMIC
CS0024	1	CORD SET, 12/3 SJTO 8' 30"LEAD
LH0021	1	LAMPHOLDER, #62602 HI TEMP
M0093	1	MOTOR BLOWER ASSY 120V
S0356	1	SWITCH, ROCKER 16A 250V
WB31251500	1	PACKAGE HOLDER
WB31252000	1	PERFORATED PAN INSERT
WN31250700	1	CRUMB CATCH
FB31250803	1	PAN DIVIDER
PL0004	1	PILOT LIGHT
FB31257003	1	FLAT SURFACE INSERT


HFWB



PART #	QTY	DESCRIPTION
B0066	1	BULB, 40A15 130V PTFE COATED
C0119	1	CALROD, 120V 1000W 140C C/U SWITCH
C0080	2	CALROD, 120V 400W CERAMIC
CS0024	1	CORD SET, 12/3 SJTO 8' 30"LEAD
LH0021	1	LAMPHOLDER, #62602 HI TEMP
M0093	1	MOTOR BLOWER ASSY 120V
S0356	1	SWITCH, ROCKER 16A 250V
WB31256800	1	PACKAGE HOLDER
WB31253900	1	PERFORATED PAN INSERT
WN31253100	1	CRUMB CATCH
FB31253803	1	PAN DIVIDER
PL0004	1	PILOT LIGHT
FB31257403	1	FLAT SURFACE INSERT









HFWS




PART #	QTY	DESCRIPTION
B0066	1	BULB, 40A15 130V PTFE COATED
C0119	1	CALROD, 120V 1000W 140C C/U SWITCH
C0080	2	CALROD, 120V 400W CERAMIC
CS0024	1	CORD SET, 12/3 SJTO 8' 30"LEAD
LH0021	1	LAMPHOLDER, #62602 HI TEMP
M0093	1	MOTOR BLOWER ASSY 120V
S0356	1	SWITCH, ROCKER 16A 250V
WB31260600	1	PACKAGE HOLDER
WB31262300	1	PERFORATED PAN INSERT
FB31250705	1	CRUMB CATCH
FB31250803	1	PAN DIVIDER
PL0004	1	PILOT LIGHT
FB31260803	1	FLAT SURFACE INSERT, PACKAGE HOLDER

**Accessories**

PART #	DESCRIPTION	PICTURE
WB31251500	PACKAGE HOLDER (HFW)	
WB31256800	PACKAGE HOLDER (HFWB)	
WB31260600	PACKAGE HOLDER (HFWS)	
WB31252000	PERFORATED PAN INSERT (HFW)	
WB31253900	PERFORATED PAN INSERT (HFWB)	
WB31262300	PERFORATED PAN INSERT (HFWS)	
WN31250700	CRUMB CATCH (HFW, HFWS)	
WN31253100	CRUMB CATCH (HFWB)	
FB31250803	PAN DIVIDER (HFW, HFWS)	
FB31253803	PAN DIVIDER (HFWB)	
FB31261803	CARTON HOLDER MEDIUM	
FB31261903	CARTON HOLDER LARGE	
FB31257003	HFW FLAT SURFACE, INSERT (PACKAGEHOLDER)	
FB31257403	HFWB FLAT SURFACE, INSERT (PACKAGEHOLDER)	
FB31260803	HFWS FLAT SURFACE, INSERT (PACKAGEHOLDER)	

# Wiring Diagrams

**HFW**





2812 Grandview Dr., Simpsonville, S.C. 29680, USA  
<http://www.bkideas.com>

Made and printed in the U.S.A  
L19999/082007

CS-TM-034.01

Revised 3/28/13

**REVISION HISTORY**

<b><u>REVISION</u></b>	<b><u>DATE</u></b>	<b><u>REVISED BY</u></b>	<b><u>DESCRIPTION</u></b>
01	03/28/13	KW	Initial Release-Supersedes all previous releases